

AC Voltage Detector







AC Voltage Detector

How to test voltage presence

Use the white pin near the wire, the white pin will glow and buzz if the wire is working.



Replace batteriesPlease replace the batteries inside if the light or sound is too weak. Please refer to the following picture to replace batteries.



CAUTIONS

Never test voltage above 1000 V AC. Never use the detector when damaged. Do not touch the white pin. Wipe the detector with a dry soft cloth. Only use the white pin for testing voltage.