

ST-9312A Waterproof T-Bar Corkscrew Thermometer

Instructions For Use

Functions

Range -50°C to 150°C

On/Off, Test/ Data hold

Operation

Press the On/Off button once to switch the thermometer on. Press again to switch off.

Press H/T once to hold the temperature on the display. The thermometer can now be removed from the sample being tested but still retain the recorded temperature on the display. Press again to revert back to normal testing.

The probe should be immersed to a minimum depth of 10mm.

Changing the Battery

Remove the 4 rubber bungs in the screw holes to reveal 4 screws. Remove the screws and separate the head. Replace the battery (PL-13 Button Cell). Put the head back together ensuring the silicon sealing ring is in place at the joint. Screw the head back together and replace the rubber bungs.

Warranty

The product is warranted for 12 months from date of purchase. Should you need to return the product to us please include a copy of the invoice as proof of purchase.



ATP Instrumentation Ltd
Tournament Way
Ivanhoe Industrial Estate
Ashby De La Zouch
Leicestershire
LE65 2UU

Tel 01530 566800

Fax 01530 560373

Email sales@atp-instruments.co.uk

Web Site www.atp-instrumentation.co.uk

