

ATP DIGITAL THERMO HYGROMETER - HT-1026HI

RANGE: Temperature: Indoor: -10°C to 50°C (14°F to 122°F) Outdoor: -50°C to 70°C (-58°F to 158°F) (if applicable)

Relative Humidity: 20% to 95% (if applicable)

MAX/MIN MEMORY:

Press the MAX button once to show the maximum records of temperature and humidity.

Press the Max button again to return to current readings.

Press the MIN button once to show the minimum records of temperature and humidity.

Press the MIN button again to return to current readings.

Press the RESET button to reset the MAX or MIN record when record is displayed.

SWITCHING BETWEEN CELSIUS & FAHRENHEIT:

Press the C° / F° button once to switch between the temperature unit.

SWITCHING BETWEEN INDOOR & OUTDOOR TEMPERATURE:

Press the IN/OUT button to switch between indoor and outdoor temperature.

IN and OUT indicator will be displayed to show whether it is indoor or outdoor temperature.

5 LEVEL COMFORT INDICATOR:

Comfort Indicator is shown according to the Human-perceived temperature to indicate the feeling of the environment.

ONE BAR = very uncomfortable

TWO BARS = uncomfortable

THREE BARS = generic

FOUR BARS = comfortable

FIVE BARS = very comfortable

BATTERY: 1.5v AAA

