

# HT-9237 Digital Pen-Type Thermo-Hygrometer

## Specifications

<b>Temperature</b>	0°C to 50°C or 0°F to 122°F
<b>Resolution</b>	0.1°C or 0.1°F
<b>Accuracy</b>	+/- 1°C or +/- 1.8°F
<b>Humidity</b>	20% to 100%RH
<b>Resolution</b>	0.1%RH
<b>Accuracy</b>	+/- 3%RH from 30% to 70%RH, (otherwise +/-5%RH)
<b>Power</b>	1 x 3V CR2032 Button Cell

## Features

On/Off  
Min Max memory since power on  
°C/°F Selection  
Soft Touch Rubberised Plastic Housing  
Sintered Rotating Sensor Protector

## Operation

Power "on" by pressing on/off button  
Power "off" by pressing on/off button  
Rotate sintered sensor protector to expose the sensors  
Press °F/ °C button to select temperature format  
Min Max Memory. Press min/max button once to display the maximum recorded values since power on. Press the same button again to display

## Warranty

The product is warranted for 12 months from date of purchase. Should you need to return the product to us please include a copy of the invoice as proof of purchase.



**ATP Instrumentation Ltd  
Tournament Way  
Ivanhoe Industrial Estate  
Ashby De La Zouch  
Leicestershire  
LE65 2UU**

**Tel 01530 566800**

**Fax 01530 560373**

**Email [sales@atp-instruments.co.uk](mailto:sales@atp-instruments.co.uk)**

**Web Site [www.atp-instrumentation.co.uk](http://www.atp-instrumentation.co.uk)**

