

Professional Quartz Timer

- 1/100th sec stopwatch
- Split/lap time
- Normal time
- Hours, Minutes, Seconds
- Day, Date, Month
- A Must for all sport and technical applications



FUNCTION READING

Normal display: Hour, minutes, second and day of the week

Push A: for alarm time

Push B: Mode

Push C: for month, date, day of the week

STOP FUNCTION

Push B for stop function

Push C for count & stop

Push A for lap & reset

ALARM & CHIME ON / OFF

Chime is auto-built-in into the IC, no more chime flag is required

Alarm () on and off

In normal time hold A then push C

Alarm flag appears alarm on/alarm flag disappears, alarm off

ALARM TIME SETTING

Press B 2 times makes hour flashing, press C to advance

Push A again to make minute flashing, press C to advance

Push B 1 time back to normal time

NORMAL TIME SETTING

Press B 3 times then push A once to make flashing of minute, push C to advance

Press A again to make flashing of hour, push C to advance

Repeat the sequence until the week days to be set, then press B once back to normal time.

Select 12/24 hour cycle option in normal time

Press B 3 times, then A 2 times so that hour is flashing,

press C to advance 1 cycle to select

12/24 hour, after selected, press B 1 time back to normal time.

BATTERY

When readout becomes dim or no displays, it is time to replace the battery.

Remove the back cover by loosening the screw and replace with 0% HG.PB or LR1130 or G10-A.