


Professional Quartz Timer



FUNCTION READING

Normal display: Hour, minutes, second and day of week

Push of A : For alarm time

Push of B : Mode

Push of C : For month date, day of week

STOP FUNCTION

Push B for stop function

Push C for count & stop

Push A for lap & reset

ALARM & CHIME ON/OFF

Chime (🔔) on and off

In normal time hold A then push C or hold A then push B

Chime flag appear, chime on chime flag disappear chime off

Alarm (🔔) on and off

In normal time hold A then push C

Alarm flag appear alarm on alarm flag disappear alarm off

ALARM TIME SETTING

Hold B about 3 seconds or push B once by once

(Day of week flag above Monday flashing)

Push C or A to change hour / minutes function

then advance figure by pushing A or C

Push B to normal time

NORMAL TIME SETTING

Hold B about 3 seconds then push B once or push B once by once

(Day of week flag above Tuesday flashing)

Select flashing digit(s) to be set by push C or A

Advance figure by pushing A or C

Select 12/24 hour cycle option in normal time

Hold A then push B or when time (hour) setting, 12/24 hour

cycle option will appear alternately on every 24 hour cycle

during hour advance Month and date interchange by holding C

then push A or cannot be changed

BATTERY

When readout becomes dim or no displays, it is time to replace the battery remove the back cover by loosening the screw and

replace with UCC 392 Renata 2 or Toshiba LR61

- 1/100th sec stopwatch
- Stopwatch
- Normal time
- Hours, Minutes, Seconds
- Day, Date, Month
- A Must for all sport and technical applications

